

Installation and Operating Instructions Addendum

High Efficiency Condensing Combi Boiler

99,000 & 125,000 Btu/hr Models

160,000 & 199,000 Btu/hr Models

The following replaces the version found in the *High Efficiency Condensing Combi Boiler 99,000 & 120,000 Btu/hr and 160,000 & 199,000 Btu/hr Installation and Operating Instructions* dated April 2022.

Page 2

- 1 x Propane Conversion Kit: Part # P-081034 (99,000 Btu/hr) or Part # P-081054 (125,000 Btu/hr) or Part # P-081744 (160,000 Btu/hr) or Part # P-081014 (199,000 Btu/hr)

Page 1-18

⚠ NOTE

Combustion air connection may be moved from one side to the other:

- Remove the retaining clip screws then lift tab at back of plug and rotate 1/8th of a turn counter-clockwise to remove from top of cabinet.
- Remove the retaining clip by removing both screws then lift tab at back of combustion air connection and rotate 1/8th of a turn counter-clockwise to remove from top of cabinet.
- Reinstall plug and combustion air connection in the desired locations then rotate 1/8th of a turn clockwise until tab latches into the top of the cabinet.
- Reinstall the retaining clip over the combustion air connection tab and secure with two screws. Reinstall two screws in the top of the cabinet near the plug.

PROPANE ORIFICE CHART	
MODEL	ORIFICE SIZE
99,000 Btu/hr	327
125,000 Btu/hr	392
160,000 Btu/hr	440
199,000 Btu/hr	535

NATURAL GAS ORIFICE CHART	
MODEL	ORIFICE SIZE
99,000 Btu/hr	415
125,000 Btu/hr	480
160,000 Btu/hr	580
199,000 Btu/hr	660